

INSTRUCTIONS

To Assemble Your Tree

SUMMARY

To assemble a Christmas tree can be easy and quick. Please check and follow the instructions listed below. For any question, please feel free to contact us.

tony@pinefields.cn

List:

ASSEMBLY & USE INSTRUCTION FOR HINGED TREE	2
Caution:	2
Before You Start:	2
Assembly:	2
Care & Use:	3
Storage:	3
Disposal and recycling:	3
ASSEMBLY & USE INSTRUCTION FOR PRELIT HINGED TREE	4
Caution:	4
Before You Start:	4
Assembly:	5
Care & Use:	5
Storage:	5
Trouble shooting:	6
Disposal and recycling:	6
User Manual for WIFI APP – Multifunction Light Set	7
Getting Started:	7
APP Functions:	7
How to Control the Led Lights from your cellphone:	Q

ASSEMBLY & USE INSTRUCTION FOR HINGED TREE

THESE INSTRUCTIONS ARE FOR YOUR SAFETY. PLEASE STUDY ALL INSTRUCTIONS AND WARNING LABELS BEFORE USING AND RETAIN FOR FUTURE REFERENCE.


Caution:

- Product is intended for indoor use only.
- Do not use this product for any other purpose than its intended use.
- Do not allow the product near/ contact with a source of heat or flame, e.g., gas or electric heaters, fireplaces, candles, or other similar heat sources.
- Unplug the light chain (if any) when leaving the house, when retiring for the night, or if unattended.
- This product is for decoration use only. Not to be used by children as a toy and watch over them when near the tree.
- Ensure tree is stable, place on a firm and level surface, away from where it may be knocked.
- Keep out of reach of small children.

Before You Start:

- 1. Study the Caution carefully.
- 2. Decide on an appropriate location for your product, make sure that you have plenty of space, a level surface and a clean dry area for assembly and locate. Always try to assemble the product as close as possible to the intended location.
- 3. Check the pack and make sure you have all the parts.
- 4. Remove all plastic bags and dispose of safely.
- 5. Retain the instructions for future use.

Assembly:







Fig.1

- 2. Insert the bottom tree section into the tree stand and tighten the 3 screws on the stand.
- 3. Insert the middle tree section into the bottom tree section and push down into position, as shown Fig. 2.
- 4. Insert the tree-top into the middle tree section and push down into position, as shown Fig. 2.
- 5. The branches are hinged on the bottom and middle sections, and will fold down automatically into the predesigned angles, as shown Fig. 3.



6. Finally shape the tree by arranging the tips on the branches to give the desired effect. Some tree styles have "side branches" attached to the main branch stem that require additional shaping as shown Fig. 4. After shaping the complete tree, the finished look should be natural and full.







ig.4

Care & Use:

- Before using or re-using, inspect the product carefully. Throw away the products if any parts damaged or frayed wire insulation or cords, loose connections, or exposed copper wire.
- Before storing the product, carefully remove the product from wherever it is placed to avoid undue strain or stress on the product conductors, connections, and wires.

Storage:

- 1. Unplug the light-chains from the mains socket and remove all decorations from the tree.
- 2. Gently disconnect the cable connectors.
- 3. Gently lift off the tree-top and middle and bottom sections and remove the tree stand.
- 4. Carefully place the tree in its box and tape it shut.
- 5. STORE THE PRODUCT IN A COOL AND DRY LOCATION PROTECTED FROM SUNLIGHT AND WHERE THE TEMPERATURE DOES NOT EXCEED 40 Celsius degrees.

Disposal and recycling:



- Waste electrical products should not be disposed of with household waste.
- Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

ASSEMBLY & USE INSTRUCTION FOR PRELIT HINGED TREE

THESE INSTRUCTIONS ARE FOR YOUR SAFETY. PLEASE STUDY ALL INSTRUCTIONS AND WARNING LABELS BEFORE USING AND RETAIN FOR FUTURE REFERENCE.

Caution:

- Product is intended for indoor use only.
- Always insert the power-plug into an indoor mains socket.
- Do not use this product for any other purpose than its intended use.
- Never place the product near a wet location.
- Do not allow the product near/ contact with a source of heat or flame, e.g., gas or electric heaters, fireplaces, candles, or other similar heat sources.
- Do not cover the product with cloth, paper, or any other material not part of the product when in use, for example, curtains, nets, or bedding.
- Do not connect the product to the power supply while the product is in the packaging.
- Do not connect the light set to any other light set by cutting or joining the sets together.
- Unplug the light chain (if any) when leaving the house, when retiring for the night, or if unattended.
- Do not secure the wiring with sharp hooks or nails. This can cut or damage the wire insulation.
- The external flexible cable or cord cannot be replaced. If part of light set or cable is damaged, the product MUST be destroyed.
- This product is for decoration use only. Not to be used by children as a toy and watch over them when near the tree.
- Ensure tree is stable, place on a firm and level surface, away from where it may be knocked and do not overload with excessively heavy decorations.
- Keep out of reach of small children and pets.
- To avoid the risk of fire, burns, personal injury, and electric shock it should not be played with or placed where small children can reach it.
- IF YOU ARE IN ANY DOUBT ABOUT INSTALLING THIS PRODUCT, CONSULT A QUALIFIED ELECTRICIAN.

Before You Start:

- 1. Study the Caution carefully.
- 2. Decide on an appropriate location for your product, make sure that you have plenty of space, a level surface and a clean dry area for assembly and locate. Always try to assemble the product as close as possible to the intended location.
- 3. Check the pack and make sure you have all the parts.
- 4. Remove all plastic bags and dispose of safely.
- 5. Retain the instructions for future use.

Assembly:

- 1. Choose a location where the tree is to be displayed. Take out the tree stand, pull apart the legs of stand so that they are "X" shaped as Fig. 1, place it on a flat surface.

Fig. 4

- 2. Insert the bottom tree section into the tree stand and tighten the 3 screws on the stand.
- 3. Insert the middle tree section into the bottom tree section and push down into position, as shown Fig. 2.
- 4. Insert the tree-top into the middle tree section and push down into position, as shown Fig. 2.
- 5. The branches are hinged on the bottom and middle sections, and will fold down automatically into the predesigned angles, as shown Fig. 3.
- 6. Fit the cable connectors together, one set between the tree-top and the middle tree section, and the other set between the middle tree section and the tree-bottom.

 Ensure the connectors are securely tightened (per Fig 4).
- 7. Finally shape the tree by arranging the tips on the branches to give the desired effect. Some tree styles have "side branches" attached to the main branch stem that require additional shaping as shown Fig. 5. After shaping the complete tree, the finished look should be natural and full.
- 8. Put the power plug at the bottom of the whole tree into an INDOOR mains socket to turn on the lights.



Care & Use:

- Before using or re-using, inspect the product carefully. Throw away the products if any parts damaged or frayed wire insulation or cords, loose connections, or exposed copper wire.
- Before storing the product, carefully remove the product from wherever it is placed to avoid undue strain or stress on the product conductors, connections, and wires.

Storage:

- 1. Unplug the light-chains from the mains socket and remove all decorations from the tree.
- 2. Gently disconnect the cable connectors.
- 3. Gently lift off the tree-top and middle and bottom sections and remove the tree stand.
- 4. Carefully place the tree in its box and tape it shut.
- 5. STORE THE PRODUCT IN A COOL AND DRY LOCATION PROTECTED FROM SUNLIGHT AND WHERE THE TEMPERATURE DOES NOT EXCEED 40 Celsius degrees.



Trouble shooting:

If the product does not work properly, check these connections:

- Make sure that the product is securely plugged to the power supply.
- Check that the cable connectors are securely connected.

Disposal and recycling:



- Waste electrical products should not be disposed of with household waste.
- Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

User Manual for WIFI APP – Multifunction Light Set

Getting Started:

- 1) Download the "Tuya Smart" tuya app to your mobile device from the IOS App Store or Google Play.
- 2) Open the app and sign up an account.
- 3) Switch on the light set. A blue signal light on the transformer will be flashing after few seconds. Or holding the function button of the transformer few seconds to active the blue signal light. The light set is now on a WIFI connecting mode.
- 4) On the app, follow the screen instructions to search the light set.
- 5) Add the light set to the APP by choosing the WIFI network and input the password.
- 6) The flashing blue light would be switch off when the set is successfully added to the APP. And you can now enjoy the mobile app control.

The light set can be connected to one device only. But user can share the control with others by using "Share Device" setting. To using this function, select the light set on the device, then clicking the configuration icon on the right top conner, choosing "Share Device" and follow the instruction to complete the setting.

The App supports group control. If you have more than one WIFI light set, you can create a group and add the device on. Devices in the same group can be controlled together. To using this function, select the light set on the device, then clicking the configuration icon on the right top conner, choosing "Create Group" and follow the instruction to complete the setting.

APP Functions:

User can control the following by clicking the device under the "Tuya Smart" toya app On / Off



Light Mode Selection: 1) Combination; 2) In Waves; 3) Sequential; 4) SLO-GLO; 5) Chasing/Flash; 6) Slow Fade; Twinkle/Flash; 8) Steady On



Frequency and Brightness – Please clicking the right top corner on the light mode to open the setting.



Rhythm Light Mode - The flashing frequency will change with the rhythm of the sound and music collected by the mobile phone. To using this function, please ensure your mobile setting allow the app to access "Microphone" function.




Timing Configuration – The light set can be scheduled Light-off / Light -on with particular light mode according to the set time and function. Or user can simply schedule the On/ Off by "Scene" function under the App.

How to Control the Led Lights from your cellphone:

- Download the APP TUYA from Google Play or App Store and install it on your cell phone;
- 2. Make sure the Wi-Fi of your mobile is turned on;
- 3. Open the App and follow the instructions to add the Device named "Christmas Lights" or "圣诞灯";
- 4. Control or set up the functions of the lights from the APP on your cell phone:







----end----